

This Page Is Inserted by IFW Operations
and is not a part of the Official Record

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

IMAGES ARE BEST AVAILABLE COPY.

**As rescanning documents *will not* correct images,
please do not report the images to the
Image Problem Mailbox.**




FIG. 1




FIG. 2




FIG. 3




FIG. 4A




FIG. 4B




FIG. 4C




FIG. 5




FIG. 6A




FIG. 6B




FIG. 7





FIG. 8

Parametric Trend Chart: Results for one test, for an entire wafer






FIG. 10




FIG. 11




FIG. 12A




FIG. 12B






FIG. 13

Composite Addition



Cumulative Squared Method

Done on X,Y location basis for entire dataset / Lot






FIG. 15A






FIG. 15B

Exclusion Zone Graphical Representation



Description

The exclusion zone function is designed to exclude certain devices based on specific x,y locations read from a file or devices within a certain distance of the edge of the dataset that meet a specified criteria. Devices are excluded by setting them to a value which is out of the range of subsequent processes such as proximity weighting.

Logic

Loop through each x,y location
 If x,y location is within EXCLUSION_RANGE of the edge of the data set then
 Check if x,y location value (bin) meets EXCLUSION_CRITERIA
 If EXCLUSION_CRITERIA is met, set x,y location to EXCLUSION_INK_VALUE

Process EXCLUSION_FILE and set all x,y locations listed in file to EXCLUSION_INK_VALUE

Examples

Device A would be excluded
 Device B would be excluded
 Device C would be excluded
 Device D would be included

Parameters

EXCLUSION_RANGE = 1
 EXCLUSION_INK_VALUE = -1
 EXCLUSION_CRITERIA = "Good_Bins = 0"
 EXCLUSION_FILE = "D:/Step2/my.exclude"

FIG. 16




FIG. 17A




FIG. 17B

Proximity Weighting Graphical





FIG. 18

Description

Proximity Weighting reviews all data points in a data set arranged in x,y fashion and analyzes the points that have values within a specified range. Analysis consists of searching an area, radius of specified units, around each device and looking for devices that are above a certain threshold. If a device is found that has a value above a said threshold, then it either lends a specified weight to the device being analyzed; weight depends if the device is adjacent or diagonal to the device being analyzed.

Logic

Loop through each x,y location

If x,y location has value between UPPER_BOUND and LOWER_BOUND

Check all devices in the specified search range (see legend)

If device in search range being checked has a value that meets or exceeds the INFLUENCE_VALUE then

If device is adjacent, increment x,y location count by ADJACENT_VALUE else increment x,y location count by CORNER_VALUE

If x,y location is on edge of dataset then multiply by x,y location count by EDGE_FACTOR


If x,y location count exceeds THRESHOLD, assign x,y location a value of INK_VALUE

Examples


- Count = 2, end result = 1
- Count = 6, end result = 20
- Count = 0, end result = 1
- Count = 6, end result = 20

Parameters



THRESHOLD = 4 ADJACENT_VALUE = 2
 CORNER_VALUE = 1 EDGE_FACTOR = 1
 PROX_RANGE = 1 UPPER_BOUND = 30
 LOWER_BOUND = 0 INK_VALUE = 20
 INFLUENCE_VALUE = 30



Cluster Detection



Legend

-  = Devices that have values matching the DEFINITION_VALUE
-  = Group Index

Description

The cluster detection function's purpose is to remove groups of locations (defined by the DEFINITION_VALUE) in datasets by ascertaining how large each group is and if smaller than a said threshold, remove the group(s).

Logic

Loop through each x,y location
 If there is a device at the x,y location
 If x,y location has value equal to DEFINITION_VALUE
 Call recursive function find next device in group and assign group index

Once group indexes have been assigned, count how many devices are assigned to each group
 If group count is less than SIZE_THRESHOLD, remove it / set value to bin one

Examples

- Group 1: Would be removed
- Group 2: Would be kept
- Group 3: Would be kept

Parameters

SIZE_THRESHOLD = 8
 DEFINITION_VALUE = 30
 INCLUDE_CORNERS = 1

FIG. 20

Percentage of Pattern Composite Map Definition




FIG. 24

Absolute Composite Merge






FIG. 21



Description:

Looking at the example to the left, notice that there are two composite map patterns, labeled one and two. Notice that there is an area where the two patterns overlap, it is this area and only this area of overlap that will be merged into the original data if and only if a user defined criteria is met. This criteria could be a fixed threshold, 15 for instance or a calculated value such as 90% of the data points constituting the patterns must overlap. In either case, the overlap on the upper left portion of the diagram would have sufficient overlap and would be merged but the overlap on the right of the diagram has only four devices and would not be merged.

Note: It is also possible that instead of merging only the overlapping patterns that all patterns are merged regardless of the criteria and the data points that do meet the criteria are only noted in an output file.



Description:

Looking at the example to the left, notice that there are two composite map patterns, labeled one and two. any points from either pattern are merged in this type of merge operation.

Composite Pattern Constitution






FIG. 23

Legend

-  Tester Bin Failures in original data
-  Failure Pattern in Composite Map

Pattern Constitution Mode

Given the example on the top left and assuming that the user has set the criteria for a pattern merge is that at least 50% of the composite map pattern must match the original data we can see that the composite pattern would not be merged on the original data. This is due to the failure of the data to pass the criteria specified, at least 8 out of the 16 data point pattern must have corresponding point on the original data, of which there are only six. Since the pattern failed the criteria it will not be merged with the original data.

Absolute Mode

In this mode, the example to the left would have the composite map super imposed over the original data map regardless of how much of the pattern is representative of the actual data.

Multiple Recipe / Overlapping Composite Map Definition








FIG. 22

Legend

-  Tester Bin Failures in original data
-  Failure Pattern in Composite Map 1
-  Failure Pattern in Composite Map 2
-  Composite Maps Overlap

Description:

Looking at the example to the left, notice that there are two composite map patterns, labeled one and two. Notice that there is an area where the two patterns overlap. It is this area and only this area of overlap that will be merged into the original data, the rest of the pattern is discarded.





FIG. 25






FIG. 27




FIG. 28




FIG. 29